

# A U T O T E C H

*sport tuning*

## Installation Instructions

www.autotech.com

**Part Number:** 10.199.022K

**Description:** HD Polyurethane Front Mount, A3 Chassis

**Notes:** Our A3 front engine mount bushing reduces engine 'rock' under acceleration, resulting in better power transfer.

### Procedure:



1) *Remove the original lower bushing from the car's front engine mount.*

First, if your car has one, remove the lower bushing retaining cover as shown (below left) by removing the three nuts with a 13mm wrench.



Next, using an 8mm hex (Allen®) wrench, remove the bottom center bolt as shown (above right) and take out the lower bushing.

2) *Install the Autotech HD bushing.*

Now, put the HD bushing in place and retain with the original bolt.  *bolt: 41ftlb/55Nm (bolt oiled).*  *nuts: 15ftlb/20Nm*

