

# A U T O T E C H

## Installation Instructions

*Sport Tuning*

**Part Number:** 10.215.455K

**Description:** Sport Tuned Boost Check Valve

### Procedure:

1. Open hood and locate the air hose leading from the idle stabilizer to the bypass tube.
2. Measure 1 1/4" from the idle stabilizer end of the hose and mark. Next, make another mark 5" from the same starting point.
3. Cut the hose at both marks, and remove the 3 1/4" section of hose that has just been cut out. The boost check valve will replace the section of hose that you have just cut out.
4. Loosen the hose clamps a little and place them over the hose at both ends. Insert the boost check valve into both ends of the hose, *with the arrow on the check valve body pointing towards the idle stabilizer*.
5. Slide both hose clamps over the hose, approximately 1/4" away from the flats on the black anodized ends of the check valve. Tighten both hose clamps.

