

# A U T O T E C H

## Installation Instructions

*sport tuning*

www.autotech.com

**PART NUMBER:** 10.425.1025GK, 10.425.1025K

**DESCRIPTION:** Front Swaybar for Rabbit, Scirocco, and Jetta 1

1. Jack up vehicle in all four corners and install jackstands at factory jacking points on vehicle.

**CAUTION:** Do not jack up vehicle in center of floor pan or under brake or fuel lines.

2. Remove A-arm pin brackets located at the front end of the floor pan.
3. Locate GTI swaybar bracket in the same position and check for interference. (On some vehicles the fuel lines may be in the way due to their height in relationship to the bracket. If interference occurs, loosen the fuel line clip near the bracket and move slightly, then take a hammer and flat punch relieve the body reinforcement channel for clearance. Reinstall the fuel lines.)
4. Install swaybar brackets to body using factory torque specs.
5. Install urethane bushing on swaybar using silicone lubricant to aid in process.
6. Install swaybar temporarily on brackets with the "U" shaped bend in end pieces inverted so that the bar ends up on top of the A-arm.
7. Snap swaybar end grommets and mounts on bar to locate holes on A-arm. (Some vehicles came from factory with holes already drilled in them for use with the bar.) mark mounting holes and remove hardware.
8. Use a 5/16" drill bit to drill the A-arm for mounting holes.
9. Install all mounting hardware for swaybar using the nuts supplied.
10. Lower car to ground and test progressively building up your speed.

TEMPLATE FOR RABBIT, SCIROCCO, AND JETTA 1

Template is for drilling SWAYBAR END MOUNTING BRACKETS.

NOTE: Some vehicles may already have these holes pre-drilled in A-ARMS.

