

Installation Instructions

www.autotech.com

Part Number: 10.425.1632GK

Description: L/W FRONT SWAYBAR FOR B5 PASSAT

Notes:

This swaybar is a direct replacement for the original one. It is a simple, bolt on installation.

Procedure:

- 1) Place the car on jackstands so that both of the front wheels are off the ground.
- 2) Remove the nut (1) that retains the outer link to the stock swaybar, and pull the link out of the bar.
- 3) Unscrew the hexnuts (2) that retain the inner bushing clamps to the chassis and remove the clamps.
- 4) Install the new bushings onto the new swaybar, using a liberal amount of waterproof grease (moly grease for cv joints works well).
- 5) Install the new swaybar in the original position and mount the inner bushing clamps.
🔧 Tighten nuts (2) to 30Nm / 22 ft lbs.
- 6) Push outer link into the swaybar end and install nut.
🔧 Tighten nut to 90Nm / 66 ft lbs.

