

A U T O T E C H

sport tuning

Installation Instructions

www.autotech.com

Part Number: 10.998.221K - supplement to 10.998.220K
Description: SHOCK THERAPY® IGNITION WIRES - 2.0L 16V
Notes: No 1 wire assembly instructions

Procedure:

- 1) Unplug the impulse sender from the harness connector.
- 2) Remove your car's original impulse sender- This is done by unscrewing the cap end connector from the number 1 wire. Once the connector is off, simply slide the impulse sender off the wire.
- 3) Using a 5/16" (8mm) drill bit, enlarge the hole through the sender.
- 4) Slide the impulse sender onto the new Shock Therapy® number one wire, which is supplied with the cap end unassembled.
- 5) Lubricate the inside of the new cap connector, as well as the white portion at the end of the Shock Therapy® wire with silicone spray. Attach the connector to the wire by pushing it over the crimped-on sleeve, then turning clockwise while pushing to engage the metal-to-metal screw-in connection.
- 6) Install the wires on the car as per instructions.