

## Installation Instructions

www.autotech.com

**PART NUMBER:** 10.109.055;

**DESCRIPTION:** oil controller for 8 valve engines

1. Remove cylinder head cover, be carefull not to let any foreign object fall down into the cylinder head.
2. Place oil controller on top of camshaft while aligning holes in controller with cam cap studs. No bolt in is required. Note the the end with the partial bolt holes on the controller should be placed near the timing belt gear.
3. Replace your cylinder head cover and tighten bolts to 7 ft/lbs. Check for leaks before normal operation is resumed.

