

Installation Instructions

www.autotech.com

Part Number: 10.715.098K-099K
Description: 4 & 5 Speed Linkage Replacemnet Kit

Fig.3-4: is an exploded view of the shift linkage used with O20 5-speed transmissions as taken from the Robert Bentley Repair Manual; the linkage used with 4-speed transmissions is nearly identical. You can use this illustration as your guide for disassembling and assembling the shift linkage. In removing the front selector rod or the rear selector rod, use a screwdriver to press back the clips on the plastic rod ends before you attempt to detach the rod ends from the ball pins of the levers.

On vehicles with 4-speed transmissions, the part labeled selector lever is shorter replacement selector levers have two ball pins. On vehicles with 5-speed transmissions, connect rear selector rod to the ball pin **B**. On the vehicles with 4-speed transmission, connect rear selector rod to ball pin **A**

